



## 9. 故障排除流程图

### 9-1. 基带

#### 9-1. 开机









U408



## 9-1-2.初始化



# U408



# U500

## 9-1-3.SIM部分

